

Reading output files with Matlab (examples)

Three different matlab functions can read sunfluidh output files. [Download the files](#). Make sure the directory where you have untar these files is listed in the matlabpath¹.

1. **read_sunfluidh_data** reads res* or rst* files
2. **read_sunfluidh_probes** reads all probes files *_ins_*
3. **read-sunfluidh-namelist** reads check_namelist_data.dat

As for any matlab function, the documentation is built in. In the command window just type : **help** read_sunfluidh_data or **doc** read_sunfluidh_data.

Here, we assume you have already runned the case [2D laminar channel flow with a constriction](#). Make sure the current directory for matlab is also the directory where you have the output files.

Instantaneous (or statistical) fields

Visualisation of U velocity component.

```
f = read_sunfluidh_data(7) % read res_00000_0000007.d. If you omit (7), the
function tries to read the last generated file.
pcolor(f.xu,f.yc,f.U') % Note the transpose ' for f.U
axis image
shading interp
```

Add a colorbar, labels and increase the font size.

```
colorbar
xlabel('x'); ylabel('y'), set(gca,'FontSize',16)
```

Add on the same figure the contour for the isovalue 0 for the U component. The isocontour is red with a thick line.

```
hold on
contour(f.xu,f.yc,f.U',[0 0],'r','linewidth',2)
hold off
```

Extract the profiles from the instantaneous field. For instance, the U profile as a function of x for the grid nodes 48 in the y direction.

```
plot(f.xu,f.U(:,48))
```

Add another profile for grid nodes 19, labels.

```
hold on
plot(f.xu,f.U(:,19))
hold off
xlabel('x'); ylabel('U(x)'), set(gca,'FontSize',18)
```

```
grid on
```

Add a legend retrieving the coordinates of the 19 and 48 grid nodes from `f.yc`.

```
legend(['y = ', num2str(f.yc(48))], ['y = ', num2str(f.yc(19))] )
```

Plotting the profiles along the `y` direction is very similar. Here, the ghost cells are removed.

```
xind = 152; % pick an indice
plot(f.U(xind,2:end-1),f.yc(2:end-1))
xlabel('U(y)'),ylabel('y')
```

Retrieve from the namelists stored in `check_namelist_data.dat` the dynamic viscosity and the mesh size to make a title

```
nml = read_sunfluidh_namelist
nx  = nml.DOMAIN_FEATURES.CELLS_NUMBER_I_DIRECTION;
ny  = nml.DOMAIN_FEATURES.CELLS_NUMBER_J_DIRECTION;
Rey = 1/nml.FLUID_PROPERTIES.REFERENCE_DYNAMIC_VISCOSITY;
mystring = [' Profile at x= ', num2str(f.xu(xind)), ' Re = ', num2str(Rey),
...
           ', grid size = ' num2str(nx),'x', num2str(ny) ];
title(mystring)
```

For statistical fields you can use `read_sunfluidh_data`. You just need to add the `'stat'` option (see **doc** `read_sunfluidh_data`). For statistical fields all data are centered on scalar grid points. It is also possible to center the instantaneous fields with the option `'center'`. This can be handy in a post processing when computing quantities with different velocity field components

Temporal series

The `*ins*` files or more generally temporal series are ASCII files in which the first column is time and the first line is a header. There is no special needs to have a script for these files. You can use directly builtin MATLAB functions that you can tailor to your needs.

Conversely, you can use **`read_sunfluid_probes.m`** that attempts to read in the current directory all the `*ins*` files and build a structure with the variable names. It is quite fragile and may fail.

Reading the file `resid_L2_Li.d` with builtin MATLAB function

```
s = importdata('resid_L2_Li.d');
time = s.data(:,1);
L2 = s.data(:,2);
Linf = s.data(:,3);
semilogy(time,L2)
grid on
xlabel('t'); ylabel('L2 norm')
```

Plotting the `U` velocity component for the second probe with builtin MATLAB function

```
s = importdata('u_ins_00000.d',' ',1)
time = s.data(:,1);
u2 = s.data(:,3);
plot(time,u2)
grid on
xlabel('t'); ylabel('u probe2')
```

Using `read_sunfluidh_probes.m` makes the same job a bit easier.

```
s = read_sunfluidh_probes;
plot(s.time,s.u(:,2))
```

1)

For Unix system you can add the following command in `~/.bashrc` : `export MATLABPATH='directory_where_the_files_are_stored'`

From:
<https://sunfluidh.limsi.fr/> - **Documentation du code de simulation numérique SUNFLUIDH**

Permanent link:
https://sunfluidh.limsi.fr/sunfluidh:sunfluidh_matlab?rev=1548164349

Last update: **2019/01/22 14:39**

